


User manual

Booster Small Chair



Important: Read the following instructions carefully before use and keep them for future reference.

Important: Lire les instructions suivantes attentivement avec utilisation et les conserver pour les besoins ultérieurs de référence.



DERYAN

**BE ADVENTUROUS
& DISCOVER**

Company Info

Company address

DERYAN
Marithaime 8
6662 WD Elst
The Netherlands

Telephone

+31 481 351 070

Email

team@deryan.com

Website

www.deryan.com

Index

Product overview	5
Minimum chair requirements	5
Assembly instructions	6
Using the 3-point harness	7
Attaching the booster seat to a chair	8
Folding the booster seat	10
Cleaning & maintenance	11
Additional safety notes	11
Warnings EN	12
Waarschuwingen NL	12
Warnungen DE	13
Avertissements FR	13


Product overview

This booster seat is designed to safely seat children at the table when attached to an adult chair. It is suitable for children who can sit upright unaided (approximately from 6 months) up to a maximum weight of 15 kg (36 months).





Minimum chair requirements

- Seat width: ≥ 390 mm
- Seat depth: ≥ 390 mm
- Backrest height: ≥ 440 mm

**Minimum dimensions
of the adult chair**




Assembly instructions




1. Remove the tray.
2. Lift the backrest upwards.
3. Open both legs fully.
4. Pull down the seat base until locked in position.

Using the 3-point harness





1. Release the buckle by pressing both sides.
2. Place the child in the seat.
3. Fasten the harness securely.
4. Adjust straps to fit snugly around the child.

Attaching the booster seat to a chair







1. Center the booster seat on the chair, ensuring that the back of the booster seat is firmly against the chair's backrest. Secure the rear attachment straps by routing them behind the chair's backrest. Tighten the rear straps until snug, but do not fully tighten them (see figure 1).
2. Next, attach the lower straps by passing them underneath the chair seat. Pull the lower straps until snug, without fully tightening them (see figure 2).



3. To ensure the booster seat is securely attached, tighten both the rear and lower attachment straps as shown. Gently pull on the booster seat to check that the straps remain secure. If any movement occurs, reposition the seat and retighten the straps until firmly secured. Ensure that the rear legs of the booster seat are fully supported and resting flat on the chair (see figures 3 & 4).


Folding the booster seat



1. Pull the bottom buckle.
2. Lift the seat base upwards.
3. Fold the frame flat.
4. Push the backrest down.
5. Attach the tray to the folded unit.

Cleaning & maintenance

- Always carried out by an adult.
- Regularly check for damage or missing parts.
- Clean plastic parts with a damp cloth.
- Do not immerse the tray in water.
- Not dishwasher safe.



Additional safety notes

- Do not use on uneven or sloped surfaces.
- Do not allow children to play near the product unattended.
- Keep away from heat sources, windows, and cords.
- Do not use as a car seat.
- Avoid prolonged exposure to direct sunlight.

WARNINGS

- Never leave the child unattended.
- Always use the restraint system.
- Ensure the booster seat is securely attached to the chair before use.
- Do not use on stools, benches, or unstable chairs.
- Always check stability before placing the child in the seat.
- Use only for children who can sit unaided (approx. 6–36 months, max. 15 kg).
- Always use the safety harness. The tray does not secure the child.
- Keep the child away when folding or unfolding the product.

WAARSCHUWINGEN

- Laat het kind nooit zonder toezicht achter.
- Gebruik altijd het veiligheidssysteem.
- Controleer altijd of de stoel goed bevestigd is.
- Niet gebruiken op krukken, banken of instabiele stoelen.
- Controleer altijd de stabiliteit vóór gebruik.
- Alleen geschikt voor kinderen die zelfstandig kunnen zitten (ca. 6–36 maanden, max. 15 kg).
- Gebruik altijd de veiligheidsgordel. Het blad is geen beveiliging.
- Houd het kind uit de buurt bij in- en uitklappen.

WARNUNGS

- Lassen Sie das Kind niemals unbeaufsichtigt.
- Verwenden Sie immer das Rückhaltesystem.
- Stellen Sie sicher, dass der Sitz korrekt am Stuhl befestigt ist.
- Nicht auf Hockern, Bänken oder instabilen Stühlen verwenden.
- Vor Gebrauch stets Stabilität prüfen.
- Nur für Kinder geeignet, die selbstständig sitzen können (ca. 6–36 Monate, max. 15 kg).
- Verwenden Sie immer den Sicherheitsgurt. Das Tablett sichert das Kind nicht.
- Halten Sie das Kind beim Auf- und Zusammenklappen fern.

AVERTISSEMENTS

- Ne jamais laisser l'enfant sans surveillance.
- Toujours utiliser le système de retenue.
- Vérifier que le siège est correctement fixé à la chaise.
- Ne pas utiliser sur des tabourets, bancs ou chaises instables.
- Toujours vérifier la stabilité avant utilisation.
- Convient uniquement aux enfants capables de s'asseoir seuls (env. 6–36 mois, max. 15 kg).
- Toujours utiliser le harnais de sécurité. Le plateau ne sécurise pas l'enfant.
- Tenir l'enfant éloigné lors du pliage/dépliage.

